

MAINTENANCE INSTRUCTIONS FOR V4A

Frequency:


Once a year

Objective of the action:


The objective of this action is to avoid dust accumulation in the propeller of the fan, which could slightly reduce its efficiency.

Necessary Materials:

No special tools are needed
The propeller is cleaned with water, soap and a brush.



1. Before doing any work on an installed product, cut the power off to the fan at the circuit-breaker.



6. Clean the propeller with a soft brush and soapy water remove the dust. Finally, dry it.



2. Remove the cover by pressing on the two green clips



7. Put the propeller back in place



3. Withdraw the collar from the black case of the fan.



8. Push the button to lock the propeller.



9. Pull the collar back in place.



5. Withdraw the propeller by pulling up the yellow button



10. Close the cover with the two green clips.

Note: Colours of wires may vary according to the kit version. Pictures not contractual.